

ActiveAhead Sense Circular Holder Datasheet

Helvar

Sensor Accessory Series



- Accessory for mounting the Active+ Sense and ActiveAhead Sense sensor to the ceiling
- Easy installation
- Suitable for flush mounting
- Sturdy structure, internal strain relief
- Available in white [5692]

Package Contents


One ActiveAhead Sense Circular holder accessory kit consists of the following parts:

- 1 x Sensor holder
- 1 x Strain relief part
- 2 x Locking springs

Note: Circular sensor holders are packed in bags of ten sets which also contains 1 x Installation Guide.

Dimensions (mm)

Dimension tolerance $\pm 0,2$ mm



Materials and Conditions

Material Specifications

Material Type	Polycarbonate
Fire Retardant	Yes
UV Protected	Yes
Colour	White, RAL 9016

Glow-wire flammability test (GWFI) 650°C (IEC 60695-2-12)

Conformity and Standards

Luminaires - Part:General requirements and tests IEC 60598-1:ed.8 2014, EN 60598-1:2015

Compliant with relevant EU directives, when correctly installed in the luminaire.

CE marked, RoHS/REACH.

For instructions on how to mount the sensor to the housing and fix the housing to the ceiling please refer to separate Installation guide [Doc. 7860429] which is available on the product website's download and links section.

Operating and Storage Conditions

Ambient temperature range: -20 °C to $+50$ °C

Storage temperature range: -40 °C to $+80$ °C

Without any additional sealing the holder itself cannot be used to provide higher classification against ingress of dust or moisture.